



INSTALLATION GUIDE

BRUSHRAIL & STEPS – GREAT WALL V200 / V240



NOTE: This product has been tested for air bag compatibility and therefore the mounting system MUST NOT be modified

IMPORTANT: Bullbar installations should only be done by a qualified person and it is the responsibility of this person to ensure correct fitment.

Read Fitting instructions carefully before fitting product to vehicle

- ❖ When installed in accordance with these instructions, the front protection bar does not affect operation of the srs airbag
- ❖ this product must be installed exactly as per these instructions using only the parts supplied
- ❖ in the event of damage to any bullbar component, contact the tuff team ASAP
- ❖ do not use this product for any vehicle make or model, other than those specified by tuff
- ❖ do not remove any labels from the bullbar or brush rails & steps

FITTING KIT BRUSHRAIL & STEPS

12	Lengths 120mm x 12mm Threaded Rod
24	12mm Spring Washers
24	12mm Nuts
18	40 x 10mm Bolts
2	Spigot Bolts
20	10mm Nylock Nuts
40	10mm Flat Washers
6	190mm Backing Plates
6	Chassis brackets
6	Extension brackets



Place brackets around chassis rails with 190mm x 5mm backing plates and 120 x 12mm threaded rod and tighten



Place step extensions onto chassis brackets with 40 x 10mm bolts, nuts and washers and leave loose



Once rail is set and level and all gaps are the same, drill the spigot and fit supplied bolt in 10mm hole and tighten.

Finished!!! Well done