

TUFF BULLBARS AUSTRALIA, 5-7 Holt Drive, (P.O. Box 1977) Torrington, Toowoomba, Queensland 4350, AUSTRALIA



Ph: 1300 BE TUFF (1300 23 88 33)
Fax: 07 4633 1236
sales@tuffbullbars.com.au
admin@tuffbullbars.com.au
feedback@tuffbullbars.com.au
www.tuffbullbars.com.au

TOYOTA LAND CRUISER 200 SERIES WAGON BRUSH RAILS - BOLT & BRACKET

<u>KIT</u>

4	130mm x 12mm threaded rod
4	150mm x 12mm threaded rod
4	170mm x 12mm threaded rod
20	12mm normal nuts
20	12mm spring washers
18	40mm x 10mm bolts
20	10mm Nylock Nuts
40	10mm Flat Washers
2	Spigot Bolts (10mm bolts)
2	140mm x 25 x 5 backing plates
4	140mm x 50 x 8 threaded backing plates
6	Chassis brackets
6	Extension Brackets
	Options: Bolt On Spigots
	Double Rails = 12 x 10mm bolts & nuts & washers
	Single Rails =6 x 10mm bolts & nuts & washers



www.tuffbullbars.com.au 1300 BE TUFF

TUFF BY NAME * TUFF BY NATURE









Front bracket driver and passenger side
Use 25 x 5 x 140mm backing plate



Middle & Back bracket driver and passenger side

NOTE: Threaded side of back plate goes to the top of the bracket





Bolt brackets to the chassis

All bracket bolts around the chassis

Attach L-shaped slotted brackets to the chassis brackets

Brackets point backwards

TIP: Tighten loosely and horizontal before fitting step





Slide brush rail onto spigots on the bullbar



Fit steps and bolt to L-shaped brackets

Make sure step is level and follows the vehicle line (Use jack to hold up if necessary)



Drill an 11mm hole vertically through the top of the rail and spigot and insert bolt – using +/-10mm bolts, nuts and washers, tighten to fasten and secure





PLEASE DON'T HESITATE TO CALL US ON 1300 BE TUFF (1300 23 88 33) IF YOU HAVE ANY PROBLEMS WITH FITTING

BEST REGARDS THE TUFF TEAM! ©